

# E-Z DISHWASHER BRACKET



## INSTALLATION BEFORE PLACEMENT OF COUNTER TOP



### STEP 1:

Place the E-Z DISHWASHER BRACKET across the dishwasher opening on top of the cabinets with the raised panels facing up and the tabs flush to the cabinet facing. Secure the bracket with (4) #6X1/2" wood screws (provided). These are the same size screws used to anchor hinges to delicate cabinet doors.

### STEP 2:

Apply silicone or rubberized adhesive caulk to the three raised panels on the bracket as shown – the bracket design will conceal any caulk squeeze out. This provides shock absorption to withstand the daily use of the dishwasher door.



### STEP 3:

The counter top can now be installed on top of the bracket. To install the dishwasher, attach the dishwasher straps to the E-Z DISHWASHER BRACKET using one of the many attachment holes. This will result in a secure and professional finished installation.



Order today at [www.chemical-concepts.com](http://www.chemical-concepts.com), or call us at 800-220-1966 to speak with our adhesive experts!

 **Chemical Concepts**  
Our customers stick with us.

[chemical-concepts.com](http://chemical-concepts.com)  
410 Pike Road  
Huntingdon Valley, PA 19006  
800.220.1966