

E-Bracket instructions

The E-Bracket works with stainless or composite sinks.

E-Brackets hang over the top of the cabinet, so ultimately the strength of the cabinet will determine the weight load capacity of E-Brackets, however, they should support over 500 lbs of weight with any decent quality cabinet. To use E-Brackets, the sink rim must be within 1.5" of the cabinet. For sink installations with greater clearance between the sink rim and the cabinet, we recommend our patented Sinkit Sink Clip installation system or our LC Brackets.

ASSEMBLY

1. Insert the tab of the support piece into the raised slot of the hanger piece.
2. Partially thread the 1/4-20x2" Phillips adjuster screw into the hole support tab.
3. Place the plastic cap over the threads of the 1/4-20x2" screw.

LOCATIONS

4. Place the assembled E-Bracket over the top of the cabinet divider wall.
5. Position the E-Bracket in locations so that it will push against the sink wall and rim when tightening.
6. The typical sink will require 4 E-Brackets, 2 on each side.
Note* combo sinks may require an LC-Bracket (Purchased separately) on the back side to support the center of the sink.
7. Rest sink onto the E-Brackets.
8. Install countertops.
9. Place a bead of silicone on the rim of the sink, then position and clamp into place by normal means.
10. Tighten the adjuster screw until snug.

Note* Do not over tighten adjuster screw, only tighten until pressure is applied to the sink.

E-BRACKETS

FAST. SIMPLE. SECURE

